#### **ILAS-E lift axle valve**



- ► For electrically controlled raising and lowering of one or more lift axles via the ERS
- ► Automatic lift axle control via the ECO Tronic EBS enables the starting aid and manoeuvring aid functions
- ▶ Equipped with several pneumatic connectors

# Ţ

### **ILAS-E - Features and benefits**

- Rapid assembly thanks to integrated connectors
- ➤ Simple construction reduces sources of errors

#### Air spring valve



- ► For the load-dependent control of airbag pressure and
- ▶ Maintaining constant ride height
- ▶ Transverse throttling between the right and left airbags
- ► Integrated connectors
- ► Valve with plastic housing

# 1

### Air spring valve - Features and benefits

- Avoids running gear instability when cornering
- Extremely high corrosion resistance
- ► Rapid installation

#### **Trailer Monitor**



- ► To display diagnostic and trailer-specific data
- ▶ Load display in kg or %
- Adjustable odometer
- ► ADR- or non-ADR variants available

# Ţ

## **Trailer Monitor - Features and benefits**

- ▶ User-friendly 3-button operation
- ► High-resolution display
- ► Warning display (and service lamp)
- Central plug connection for EBS diagnostic cable